— DRIVERS CONTROL PANEL JUNCTION

— ENGINE COMPARTMENT CONTROL BOX JUNCTION

— LEFT SIDE SWITCH PANEL AMPHENOL PLUG

— NO. 2 AMPHENOL ENGINE PLUG

NO CHARGE TELL-TALE

REGULATOR

8 Ω

4 Ω

10 Ω

CARBON STACK

RELAY RECT.

REC'I.

AUX.

BAT.

SW'H

F.

APPARATUS BOX BATTERY STUD

2 BLACK

ALTERNATOR

MAIN FIELD

BUCKING FIELD

L1

L2

L3

3 BLACK

3 BLACK

3 BLACK

10 BLACK

10 BLACK

10 BLACK

10 BLACK

14 BLACK

14 BLACK

14 BLACK

14 BLACK

16 BLACK

16 BLACK

16 BLACK

16 BLK.-BRN. TR.

14 BLK.-BRN. TR.

16 BLACK

14 BLACK

14 BLACK

14 BLACK

14